



Certified 07/21/08

IDEAlliance® Off-Press Proof Application Data Sheet

ORIS Digital Proofing System™ using ORIS PearlPROOF™ Publication for Canon x100 Series printers

SWOP®¹ Grade 5 Off-Press Proof Application Data Sheet

The IDEAlliance Print Properties Working Group has established a certification process for off-press proofs as input material to publications. In accordance with this process: "The appearance of a hard copy or monitor proof used in this application must have the ability to closely match specific CGATS or other documented characterization data sets within outlined tolerances. See further explanations and recommendations outlined on www.swop.org or www.gracol.org.

The following information is intended to assist producers and consumers in the use of vendor specified proofing materials in an off-press proof application:

I. Manufacturer

CGS Publishing Technologies International, LLC.

100 North Sixth Street, Suite 308B

Minneapolis, MN 55403

Telephone +1 (612) 870-0061

Fax +1 (612) 870-0063

II. Product

ORIS Digital Proofing System™ for Canon 5100, 6100, 8100 & 9100 printers consists of the ORIS Color Tuner™, Canon 12-color LUCIA ink sets and ORIS PearlPROOF™ Publication (PSMP) paper.

III. Introduction

The Canon printer models listed in the above section (II) are digital ink-jet proofing systems. By utilizing Canon's advanced printing technology, the combination of the FINE print head technology and the L-COA processor allow the Canon imagePROGRAF printers to produce vibrant, photo-realistic proofs at unprecedented speeds. This document contains CGS ORIS operating procedures for conformance to SWOP #5.

IV. Control Guide

IDEAlliance specifies a control guide such as an ISO 12647-7 Digital Control Strip 2007 be supplied on every off-press proof. As a minimum, any control guide used for proofing applications should contain solids for the primary process colors (YMCK), two-color overprints (RGB) and a three-color overprint (YMC), as well as a 25%, 50%, and 75% tint in stated line screen resolution of each of the primary process colors and 3-color gray patches. All control guides should be checked for accuracy of the original values. Use and interpretation of a control guide is the responsibility of the creator.



Certified 07/21/08



V. System Components

The following components and limited procedures shall be used with ORIS Digital Proofing System™ in order to achieve conformance with this Application Data Sheet.

Software: ORIS Color Tuner Pro software, ORIS Certified Proof for verification of ISO 12647-7 Digital Control Strip 2007

Measurement Devices: X-Rite i1 iSis for Calibration, X-Rite i1 Pro (non-UV) for ISO 12647-7 Digital Control Strip 2007

Setup Guide: Color Tuner Calibrate+ApplyMatch.pdf (SWOP) *Contact CGS for guide.*

VI. Finishing Procedures

Proofs should not be measured for 15 minutes to allow for ink dryback. No special Finishing requirements are needed for ORIS Digital Proofing System.

VII. Finished Proof Characteristics

A proof with the color characteristics referenced in Appendix 1 is to be expected when measured from the IDEAlliance ISO 12647-7 Digital Control Strip 2007 having been properly made to all the listed system components and finishing procedures.

Note: Three-color grays are comprised of Cyan, Magenta, Yellow: 75, 66, 66; 50, 40, 40; and 25, 19, 19 values.

X-Rite i1 Pro rev B. (Non-UV) was used to measure ISO 12647-7 Digital Control Strip 2007

(ORIS Certified Proof setup files and procedures available upon request)

VIII. Sample Proofs

CGS Publishing Technologies International, LLC. has supplied three (3) sets of hard copy proofs for retention that conform to this Application Data Sheet by an IDEAlliance certifying contractor.

Appendix 1
Characterization Data CIELab Values

IDEAlliance ISO 12647-7 Digital Control Strip 2007 for SWOP 2006 Coated #5

Patch ID Top	CIELab Data			Maximum
	L*	a*	b*	CIE ΔLab
A1	32.65	-22.26	-23.31	-
A2	56.56	-37.98	-40.93	5
A3	64.70	-26.67	-29.70	-
A4	78.29	-11.19	-11.42	-
A5	26.42	40.29	-3.23	-
A6	47.64	69.97	-3.54	5
A7	58.14	49.08	-2.95	-
A8	75.88	19.59	0.11	-
A9	47.09	-4.83	44.51	-
A10	85.43	-5.82	84.62	5
A11	86.28	-5.18	60.33	-
A12	88.09	-2.76	26.91	-
A13	54.38	-50.05	-13.62	-
A14	37.79	50.15	-21.11	-
A15	68.36	21.69	65.39	-
A16	48.86	15.14	31.31	-
A17	40.69	32.61	12.52	-
A18	33.04	22.15	-14.98	-
A19	51.08	-17.54	25.50	-
A20	36.75	-2.64	-22.16	-
A21	87.97	-0.06	3.85	-
A22	83.35	-0.16	3.31	-
A23	73.53	-0.34	2.37	-
A24	56.84	-0.35	1.34	-
A25	38.89	0.04	0.98	-
A26	27.07	0.55	1.06	-
A27	19.00	1.01	1.18	5

Patch ID Bottom	CIELab Data			Maximum
	L*	a*	b*	CIE ΔLab
B1	15.76	11.76	-23.91	-
B2	26.54	18.56	-42.01	6
B3	40.30	15.39	-31.31	-
B4	65.80	7.14	-13.75	-
B5	26.49	34.78	21.45	-
B6	47.43	64.38	42.74	6
B7	57.01	44.95	36.24	-
B8	74.61	17.32	19.99	-
B9	30.65	-35.02	14.67	-
B10	52.26	-61.49	26.76	6
B11	61.52	-39.10	20.93	-
B12	76.68	-14.80	10.89	-
B13	44.23	-17.41	-40.21	-
B14	47.52	67.23	15.19	-
B15	70.77	-24.24	58.75	-
B16	66.70	19.12	19.70	-
B17	51.52	34.92	26.64	-
B18	40.31	31.25	24.75	-
B19	45.31	-25.37	-1.12	-
B20	90.06	-0.01	4.14	3
B21	87.67	0.00	3.75	-
B22	82.19	-0.02	3.09	-
B23	71.47	-0.07	2.12	-
B24	54.70	-0.44	1.24	3
B25	39.10	-0.23	1.19	-
B26	24.73	0.21	-0.12	-
B27	10.04	0.30	0.53	-

Note: Color measurements comparing measured proof data to this reference data requires the use of a calibrated spectrophotometer.

